

Courtroom #1 Technology Reference Guide


For a tour of the courtroom technology please contact the Courtroom Deputy for your proceeding.

The Courtroom Deputy controls which input device is being displayed.

Note: The Microphones will pick up noise automatically. They DO NOT need to be spoken directly into.

Courtroom Deputy controls which input device is being displayed.


Using the VCR/DVD Player:



1. Make sure VCR/DVD is on.
2. Use VCR/DVD button to select which media type you wish to use.
3. Use the remote to push play or to do such functions as fast forward or rewind.

Using a Computer/Laptop for Presentation:

1. Connect Computer via VGA cable located in the black box on floor labeled Computer.




2. Connect the sound for the computer via volume Input/Output jack.

Tip: Ensure your computer is using the appropriate output by selecting the function CRT/LCD key on your laptop.

Using the Document Camera:

1. Make sure Document camera is plugged in and turned on.
2. Raise the DCAM lamps and DCAM camera (Use button located at the base of camera arm to release).
3. Adjust document so it is appropriately viewable on the screen.

DCAM Controls



■ SDP-950DXA

- 1. Power - Use this to turn the power on or off.
- 2. Rotate - Use this to rotate the image.
- 4. Zoom - Use this to control the size of an object projected on the screen.
- 5. AF - Use this to adjust the focus automatically.
- 6. Iris - Use this to control the brightness of the image.
- 7. Int / Ext - Use this to select internal or external image

Int: to view the image on this product.


Ext: to view the VGA output from another device such as a PC monitor or a projector by connecting it to this product.

- 8. Aperture - Use this to control the sharpness of the output image.
- 9. Freeze - Use this to freeze the image.
- 10. Lamp - Use this to turn the upper lamp or light box on or off.
- 11. AWC - Use this to adjust the color automatically.

Using Real Time Connection:

1. Connect Computer via Realtime connector located in the block box on floor labeled RTT.

Note: Please contact your CRD one week in advance to have a certified **Real Time** Court Reporter.



Questions/Comments? Please call the Help Desk at (518) - 257 - 1815

